




<u>Itemcode:</u>		<u>Servicekit 12 months:</u>
BS-MT12A		BS-MT 200-1400 Generation 0
<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <div style="border: 1px solid black; padding: 2px;">A</div> <div style="color: blue; font-size: 20px;">↓</div>  </div> <div style="text-align: center;"> <div style="border: 1px solid black; padding: 2px;">B</div> <div style="color: blue; font-size: 20px;">↓</div>  </div> <div style="text-align: center;"> <div style="border: 1px solid black; padding: 2px;">C</div> <div style="color: blue; font-size: 20px;">↓</div>  </div> </div>		
	<u>Components:</u>	<u>Quantity included:</u>
A.	Wear parts 3/2 way solenoid valve (normally open)	2x
B.	Wear parts 3/2 way solenoid valve (normally closed)	2x
C.	Reset Modul (one time)	1x